

# Is your PFD inflating without you?

## Convert it to a manual only for about \$12



LELAND GAS TECHNOLOGIES  
P/N V85201MY  
CONVERSION CAP AUTO TO MANUAL  
FOR V85000 AND V90000 ALPHA INFLATORS  
[www.MaximumInflation.com](http://www.MaximumInflation.com)



STEP 1 BUY THE CAP AND A COUPLE SPARE RE-ARMING KITS WHILE YOU'RE AT IT.



LELAND GAS TECHNOLOGIES  
[www.MaximumInflation.com](http://www.MaximumInflation.com)

STEP 2 REMOVE THE CLEAR CAP, YELLOW (OR RED) BOBBIN AND CO2 CYLINDER. PUT THE CAP AND BOBBIN AWAY SOME PLACE SAFE AND DRY. YOU'LL NEED THE CYLINDER IN THE NEXT STEP. INSPECT THE CYLINDER FOR RUST OR PUNCTURE HOLE AT THE SMALL END. REPLACE IF NEEDED.



Leland Gas Technologies  
[www.MaximumInflation.com](http://www.MaximumInflation.com)

STEP 3 SCREW ON THE YELLOW CAP, MAKE SURE THE LEVER ARM IS AGAINST THE BODY WITH THE GREEN CLIP OR PIN IN PLACE AND SCREW THE CYLINDER BACK IN.

**WARNING: YOUR PFD WILL NOT SELF INFLATE UNTIL YOU CONVERT IT BACK! YOU MUST PULL THE RED TAB TO INFLATE. INFORM EVERY USER.**

We are here for you. Please call us if you have any questions. Our voicemail system is only on if we are not in the office. So please try us during our business hours 9-5pm EST. Thank you. 1-800-984-9793